

Smoke Stalker Opacity Monitor Wiring Diagram

The Smoke Stalker will operate normally with a wide range of line voltages. This includes from 24 – 264 volts *AC or DC!* Connect the line voltage wires separately to the Brown wire (Hot or +) and Blue wire (Neutral or -).

The internal switch has a normally open contact (White wire), and a normally closed contact (Black wire), with a shared common connection (Yellow wire). Connect your Signal (or Switch) wires, one to the Yellow wire and the other to the White wire. * **TAPE OR CAP THE BLACK WIRE** as it is not used. Connect your Ground wire to the ground terminal in the wiring box.

